



Cleanroom String Mop System

Efficient cleaning of floors surfaces is critical to the overall cleanliness of the production environment. The String Mop System replicate the most effective way to clean and disinfect surfaces - WIPING. The String Mop wet wiping system is

ideal controlled environments and large surfaces with heavy soiling. Practical and convenient, it proves itself on large and small production areas and is ideally suited to distributing or mopping up large quantities of liquids. Mop heads ranging from ultraclean

laundered polyester knit, to economical nonwovens are available. A sturdy and easy to use mop cart with wringer designed to work with string mops completes the line



Cleanroom String Mop Handle & Clamp

The String Mop Handle & Clamp is a versatile string mop set suitable for almost all application areas. Your clean room staff can attach mops faster and more efficiently than ever thanks to the String Mop & Handle easy connect design.

Clamp: Features and Advantages

- Blue polypropylene mop clamp
- Latch-style swing-away bar for quick and easy mophead changes
- Easily connects to handle
- Autoclavable
- Corrosion and chemical resistant

Handle: Features and Advantages

- Anodized aluminum handle with blue polypropylene hand grip
- Fixed length at 56 inches (140cm)
- Lightweight
- Easily connects to clamp—snap lock
- Corrosion and chemical resistant
- Not autoclavable

Product	Number	Packaging	Mops/Handles/Case
Choice® Mop Handle & Clamp Set	CHMH.SET.1	One Handle and One Clamp per Case	1

Cleanroom String Mop Wringer, Cart and Buckets

Composition and Technology

- The Cleanroom Flat Mop Cart is made of high quality stainless steel and is fully autoclavable.
- Locking casters provide stability during use.
- Wringer is made of durable plastic, suitable for the one-step wet cleaning process.
- Ergonomically designed handle serves as a rest for the mop handle and makes the cart easy to maneuver in tight production areas
- Two 20 liter polypropylene buckets are color coded blue and red to differentiate between clean and dirty solutions.
- Internal bucket graduations help insure correct mixing of cleaning and disinfecting solutions



Product	Number	Qty Per Cs	Pks/Cs
Stainless Steel Mop Cart with Buckets - 2, 20 Liter Buckets, Blue, Red	BCRMOPCART1	1	1
String Mop Wringer	BCRSTRWRINGER1	1	1

Cleanroom String Mop Heads

A range of specially designed String Mop Heads are available for use with the Cleanroom String Mop System. The mop heads are available in both disposable nonwoven and re-launderable microfiber and polyester knit composite, which allow the mop head to conform to the surface being cleaned, insuring thorough particle and contaminant removal even on uneven surfaces.

BCR® Mop 1 Nonwoven Mop Head Composition and Advantages

- 100% nonwoven polyester
- Soft ,non-abrasive
- Disposable
- Economic and highly absorbent
- Autoclavable
- Recommended for ISO Class 5-8,cleanroom class 100-100,000 EU grade B/C/D



BCR® Mop 4 Knitted Polyester Mop Head Composition and Advantages

- 100% knitted polyester
- Laundered and packaged in an ISO Class 4 (Class 10) cleanroom
- Tubular knit construction with fan tailed looped ends, minimizes particle generation
- Autoclavable per standard operating procedures
- Can be laundered and re-used
- Recommended for ISO Class 3-5, cleanroom class 1-1,000 EU grade A/B/C/D
- Irradiated version available

Choice® Micro Fiber Mop Head Composition and Advantages

- White 88% polyester/12% nylon microfiber string mop with blue headband and tailband
- Microfiber yarns attract and trap dirt and debris
- Terry knit structure enhances absorbency to increase efficiency
- Tubular knit construction with sewn head and tail bands provides added durability
- Lot number assures traceability
- Chemical resistant and non-abrasive
- Autoclavable
- Can be laundered and re-used
- Recommended for ISO Class 5-8, cleanroom class 100-100,000 EU grade B/C/D



Product	Number	Packaging	Mops/Pk	Mops/Cs
BCR® Non-Woven Polyester, Unlaundered	BCM.1.12	Individually wrapped	1	12
BCR® Mop Knitted Polyester, Laundered Mophead	BCM.4.12	Individually wrapped	1	12
BCR® Mop Knitted Polyester, Laundered, Irradiated	BCM.4IR.12	Individually wrapped	1	12
Choice® MicroFiber Mop	CHMFM.24	Individually wrapped	1	24