

# KIMTECH™ N95 RESPIRATOR

**KIMTECH™ N95 Respirator** is a single-use respirator to be used by skilled professionals in critical environments who need to protect the process and are mandated to wear specific PPE to protect against the transfer of non-oil aerosolized particulate matter.

**Not tested against COVID-19 and therefore not recommended for efficacy or use. Not for medical use.**

**Product Description**

Code	Description	Color	Quantity
53358	Respirator with pouch	White	50/bag, 6 bags/case, 300 total

**Construction**

Component	Material
Inner facing	Non-irritating propylene
Outer facing	Clean durable bicomponent material
Filter Media	Electro-statically treated meltblown
Headband	Polypropylene elastomer wire weave material
Nosepiece	Flexible wire tie

**Physical Properties**

Property	Target	Test Method
NaCl Penetration	<5% @ 85 lpm	TEB-APR-STP-0059
Exhalation Resistance	<25mm H <sub>2</sub> O	TEB-APR-STP-0003
Inhalation Resistance	<35mm H <sub>2</sub> O	TEB-APR-STP-0007

**Features**

- NIOSH certified: TC# 84A-9042
- Comfortable non-irritating lining
- Flat pouch-style breathing chamber for added comfort
- Headbands of bicomponent elastomeric material
- Fits secure to face, helps ensure tight facial seal, and prevents leakage around edges
- Two layers of electro-statically treated meltblown filter media
- Provides a minimum of 95% filtration efficiency for 0.3 micron particles
- Not oil resistant



**For Additional information:** Contact your Kimberly-Clark representative or our North America Customer Service Team at (888)-346-GOKC (4652) or [KCPInfo@kcc.com](mailto:KCPInfo@kcc.com).

**Certificate of Conformance** available online at [www.kimtech.com/certificates](http://www.kimtech.com/certificates).

**K-C Confidential:** The information contained in this document is intended for the use of the addressee(s) only and may contain privileged, confidential, or proprietary information that should not be distributed publicly without Kimberly-Clark's written consent.